

[Click Here](#)



This manual is for the Club Car Precedent golf cart, which comes in both electric and gasoline-powered versions. The vehicle's specifications and features are outlined, along with safety instructions, cleaning the vehicle, and accessories. It also includes details about subsequent owner registration and vehicle specifications. For gasoline vehicles, the manual provides information on engine type (Subaru EX-40) and fueling requirements. For electric vehicles, it discusses the E.R.L.C. battery charger system. The manual emphasizes the importance of following safety guidelines and warns against potential hazards such as water exposure, battery terminal warnings, and tow/run risks.

- The vehicle manufacturer warns of potential health risks associated with exposure to certain hazards, such as lightning or other storm-related hazards. Owners should exit the vehicle and seek shelter if caught in a storm while driving.
- When disconnecting battery cables, avoid allowing tools or metal objects to contact the frame, as this could cause damage or injury.
- To safely remove battery cables, follow these steps: first, remove the positive cable, then reconnect the negative cable in reverse order. Wait 90 seconds for the controller capacitors to discharge before reconnection.
- Ensure all electrical connections are secure and properly tightened, including terminals with Battery Terminal Protector Spray to minimize corrosion.
- Owners are responsible for proper recycling of lead-acid batteries, and should contact their nearest Club Car dealer or distributor for information on how to dispose of them properly.
- Precautions must be taken when operating the vehicle, such as maintaining a safe driving condition and following rules and regulations. Before operating your Club Car vehicle, ensure that the Tow-Run switch is in the RUN position for functionality. The TOW position disables power to electrical components, preventing engine operation. For long-term storage, place the Tow-Run switch in TOW to conserve battery life. The Forward/Reverse handle on the seat support panel allows you to shift gears, with distinct positions for FORWARD (F), NEUTRAL (N), and REVERSE (R). Avoid shifting into NEUTRAL during operation as it will cause the engine to stall. The vehicle runs at reduced speed when in reverse. When parking, engage the park brake firmly to prevent rolling. Ensure that the lockout switch is engaged only for gasoline vehicles equipped with an EFI system. Conduct a pre-operation and daily safety check on your Club Car vehicle. Familiarize yourself with controls, indicators, and operation after receiving delivery. Upon stopping on a hill, use the brake pedal to maintain position instead of holding it with the accelerator pedal. Adhere to all instructions before driving and consider having an experienced operator accompany you during initial drives. When towing, ensure that the trailer meets federal, state, and local requirements for lights and brakes. Use an approved trailer or tow hitch when operating on public roads. For battery storage, follow proper disconnection procedures, including securing the negative (-) cable to prevent contact with the terminal. During storage, use Sta-Bil fuel stabilizer to preserve fuel quality. Disconnect the fuel vent line from the fuel tank vent nipple and plug it securely to prevent contamination. Looking after your Precedent golf car is vital to ensure safe operation and prevent damage. Always check tire pressure, recommended on page 70, and perform regular safety checks as outlined in page 31. If any issues are found during maintenance or inspection, do not use the vehicle until repairs are made, as this can lead to serious injury or death. It's also crucial to maintain proper battery water quality, with Club Car recommending the use of deionizer or distilled water to prevent contamination. Check the red light on your dashboard and replace the filter immediately if it comes on. Additionally, lubricate rotating joints every 100 hours or as required, and keep an eye out for loose hardware. Never overfill batteries and always refer to the maintenance manual for specific instructions. Regular maintenance can help extend the life of your vehicle and prevent costly repairs. Watering gun or bottle (CC P/N AM10818) available from authorized Club Car dealer for SPWS vehicles. Ensure battery hold-downs are tight enough to prevent movement during driving, but not so tight that they crack or buckle the case. Deionizer available for SPWS vehicles with CC Part Number 105166801. For private consumer applications, use bottled distilled water and hand pump (CC P/N 104006101). Place battery fill coupling in space between battery bucket and car body to avoid damage. When filling vehicle(s), turn off water faucet when finished. Precedent Golf Car Owner's Manual recommends OEM replacement batteries; consult authorized dealer/distributor for compatibility or algorithm updates. The ERIC charger has a USB port for data transfer, reconfiguration, and updates; keep port cover in place when not in use. Ensure cord loop dips below plug level to prevent water entry; maintain large bend radius (2) in cord to avoid tension on plug. If pins are bent, replace plug immediately; do not attempt to repair or straighten bent pins. Contact local authorized Club Car dealer or distributor for repairs. The charge status indicator lights provide information concerning charge and charger status. Leave charger connected with AC power during off-season or long-term storage; recharge batteries after 40-50 amp hours of discharge or each night to avoid deeply discharging. Use CDT diagnostic tool (CC P/N 105209501) to detect amp-hour discharge. If charger does not operate properly, contact local Club Car distributor/dealer. Do not jump start a dead battery using another battery and jumper cables; instead, consult authorized dealer/distributor for assistance. Disconnect battery and spark plug wire according to Low Maintenance Battery: Disconnecting the Battery - Gasoline Vehicles on page 16, or No Maintenance Battery: Disconnecting the Battery- Gasoline Vehicles on page 17. Underneath the drain plug (1), position a pan designed for oil changes, as shown in Figure 38. The engine requires 40.0 fl-oz of 10W-30 or 5W-30 grade SE or higher oil per change, with recommended viscosity guidelines found in Figure 39. Replace the dipstick and refer to Precedent Golf Car Owner's Manual pages 64 and 65 for further instructions. When using alternative fuels, be aware that this will void the warranty. Avoid repeatedly attempting to start a vehicle when the fuel pump is dry, as this can cause damage to the fuel pump. For assistance, visit Club Car dealer at www.clubcarddealer.com, call 1-800-ClubCar (258-2227), or scan the QR Code in Figure 40 using a QR Code reader. If you are a subsequent owner of a vehicle, it is strongly recommended that you register your vehicle with Club Car. This will enable us to contact you if necessary. Please send your name, address, and serial number(s) of the vehicle(s) to Club Car, LLC, P.O. Box [insert information]. The onboard charger is available for Precedent four-passenger electric vehicles and should be plugged into a properly grounded outlet. The AC line must have the proper input voltage for the charger and be capable of supplying sufficient current. Additionally, the following features are included: * Torque converter: Automatic, variable speed, dry type * Steering: Self-adjusting rack and pinion * Suspension: Front and rear tapered mono-leaf springs with dual hydraulic shocks The vehicle's specifications include a DC cord length of 9 ft (274 cm), weight of 6.5 lb (3 kg), and mounting configuration options. Excluded from the warranty are damages caused by factors other than defects, including poor maintenance, neglect, abuse, accident, and collision. The warranty also excludes improper charging of vehicles due to using a battery charger not approved by Club Car or using impure water in batteries. Refer to Precedent Golf Car Owner's Manual pages 70-76 for further information on warranties, limitations, and exclusions. Limitations and exclusions outlined in this document will continue to apply to both this warranty statement and any subsequent Additional Warranty Documents, up to the maximum extent permitted by law.

Club car precedent manual. Club car precedent user manual. Club car precedent service manual pdf. Club car precedent maintenance. Club car precedent service manual download.